

JUST ADD WATER



## Render It™ MULTISURFACE GREY

**MADE**  
*Right Here*

Excellent flexibility & adhesion  
Suitable for masonry, styrene, fibre cement sheets & AAC blocks  
Easy to apply one part render  
Hand mix (no drill required)  
Covers approx 2.5m<sup>2</sup> per 20kg bag (5mm thickness)

**CEMENT  
AUSTRALIA®**



for masonry surfaces, styrene,  
fibre cement sheets, AAC blocks

## HOW TO RENDER A WALL

### with RenderIt® Multisurface Grey

Render is a great way to enhance a brick or block wall. With Cement Australia's RenderIt®, just add water to create an entirely new look and finish.

- ✓ Suitable for brick, block, styrene, fibre cement sheet and AAC block surfaces
- ✓ 1 bag covers approx 2.5m<sup>2</sup> at 5mm thickness



1

Prepare by brushing loose material from the wall with a stiff brush. Dirt, cracked paint, plaster, and loose mortar can affect adhesion. Repair mortar if needed (allow the mortar to cure for 7 days to avoid cracks in the render).



2

Applying beading to external corners will help to create a neater rendered finish. Thoroughly wet the surface to be rendered with a hose on light spray setting, or with a wet brush.



3

Add RenderIt® (no more than 1 bag at a time) to wheelbarrow. Add exactly the amount of clean water per bag, instructed on the back of the packaging, and mix thoroughly. Allow to stand for 5 mins before quickly stirring again.

**Remember: too much water ruins good render!**



4

Starting from the bottom, apply render using a steel trowel in an upward pushing motion. Work render into the mortar joints to provide a relatively flat surface. Long, even, upward spreads across the surface will help achieve an even and consistent thickness.



5

After the final layer of render becomes firm, use a wooden trowel or polystyrene float to smooth and then finish to the desired texture. RenderIt® can be applied in a single coat between 2mm and 10mm, or in multiple coats. Allow 3 days to between coats to allow the render to develop maximum strength and prevent cracking.

**PRO TIP: Never render in full sun**



You can colour your render with Cement Australia's Oxide range as an alternative to painting.

Visit [cementaustralia.com.au](http://cementaustralia.com.au) to watch this how to as a video, to find our other how to guides, and to work out how much product you'll need for your project with our handy calculators



**MADE**  
*Right Here*

**CEMENT  
AUSTRALIA®**